

## **Majestic Manufacturing, Inc.**

Majestic Manufacturing, Inc. \* PO Box 128  
4536 State Route 7, New Waterford, Ohio 44445

**Subject:** Cam Lock

**ATTN: OWNER/OPERATOR**

This bulletin pertains to the operation of your Majestic unit. This Service Bulletin **must** remain with the owner's manual at **all** times. If you have any questions regarding the Bulletin, contact our office at 330/457-2447, M-F 8:00a.m.-4:30p.m. E.S.T. \*\* Fax 330/457-7490.

## **SERVICE BULLETIN**

**Date:** September 13, 1995

**S.B. Number:** 95-1

**Notice:**

Majestic Manufacturing, Inc. suggests that the Cam Lock at the rectifier be disconnected every night after operation and during all electrical storms. This is to prevent an electrical surge to the rectifier, which may destroy the diodes within.

Reassemble the Cam Lock prior to the start-up of ride operations each day.

If you have any questions on factory standards or procedures on our equipment, contact Majestic Manufacturing, Inc. during normal business hours of 8:00 a.m. to 4:30 p.m. Monday through Friday, E.S.T. at 330/457-2447 or toll free at 1-888-MAJ-RIDE.